

Mercedes Vito Diesel – What you need to know



Unlocking/locking the vehicle

Use the Mobility Card to unlock and lock the vehicle. The vehicle cannot be locked if the doors are not closed properly.

Ignition key

The ignition key is located in the compartment below the radio.

Starting the engine

The engine will start in gear selector position P only. If the gear selector is not in position P, operate the foot brake and move the gear selector forwards to P.

Parking brake (handbrake)



To release the parking brake, pull on the lever marked with a P (fig. 1) on the dashboard to the left of the steering wheel.

To apply the parking brake, press on the foot pedal (fig. 2) to the far left of the driver's footwell.



Driving

To drive off, select gear position D. To do so if the gear selector is at position P, press the foot brake and move the selector to position D.

Fuel-tank cap

The fuel-tank cap is located on the driver's side. You need to be logged in to be able to open the fuel cap, and the driver's door must be open. Now you can swing the flap rearwards. Turn the filler cap anticlockwise to remove it.

Fuel

Diesel (important: NOT biodiesel)

Gears

- 1) P = Start and stop position
- 2) R = Reverse
- 3) N = Neutral (vehicle is not secure)
- 4) D = Drive mode

The foot brake must be applied to be able to move the gear selector.



Tips and tricks

Before driving off

Give yourself plenty of time

Always reserve plenty of time to make sure you are able to return your Mobility vehicle at its station on time. Late returns will incur an additional charge.

Check the vehicle for damage

You are required to report any damage to the 24h Service Center on 0848 824 812. Exception: This does not apply if the damage has already been noted in the Mobility defect book (in the glove compartment). Simply use the on-board computer to call the 24h Service Center on 0848 824 812. You will not be charged for the call.



When driving

On-board computer

Extending or shortening your reservation
Press "Res +" to extend your reservation
or "Res -" to shorten your reservation.

Ending your reservation immediately
Press the "Res End" button.

After completing your journey

Back too soon?

If you are back at least 30 minutes before your reservation is scheduled to end, you can end the reservation immediately on the on-board computer and save money.

Check the fuel level!

Please note: The petrol tank must be at least one-third full when you hand the car back.

Left something in the car but already ended your reservation?

Not a problem – please contact the 24h Service Center on 0848 824 812.