

# Skoda Octavia 4x4 (automatic) – what you need to know

---



## Unlocking/locking the vehicle

Use the Mobility Card to unlock and lock the vehicle.



## Starting/stopping the engine

Operate the brake pedal, put the gear selector in position P and press the start/stop button.

## Fuel tank cap

The fuel tank cap is at the rear on the passenger's side. Press on the fuel tank filler flap, then swing it open forwards. Unscrew the fuel cap (**black**) anticlockwise.

## Fuel

Petroleum diesel (not biodiesel)

## Boot

To open the boot, press on the button above the number plate and pull the tailgate upwards.

## Reverse gear

Operate the brake pedal, press the button on the gear selector and move the latter to position **R**.

# Tips and tricks

---

## Before driving off

### Give yourself plenty of time

Always reserve plenty of time to make sure you are able to return your Mobility vehicle at its station on time. Late returns will incur an additional charge.

### Check the vehicle for damage

You are required to report any damage to the 24h Service Center on 0848 824 812 by your mobile telephone or by the on-board computer. You will not be charged for the call by the on-board computer.



## When driving

### On-board computer

Extending or shortening your reservation:  
Press „Res +“ to extend your reservation or  
„Res -“ to shorten your reservation.

Ending your reservation immediately:  
Press the „ResEnde“ button.

---

## After completing your journey

### Back too soon?

If you are back at least 30 minutes before your reservation is scheduled to end, you can end the reservation immediately on the on-board computer and save money.

### Check the fuel level!

Please note: The petrol tank must be at least one-third full when you hand the car back.

### Left something in the car but already ended your reservation?

Not a problem – please contact the 24h Service Center on 0848 824 812.