### DRIVING INSTRUCTIONS – ELECTRIC VEHICLE – eVito

### 1. Before setting off

Vehicle checked for any damage before setting off? 0848 824 812

In the event of damage:

Disconnect the charge cable from the vehicle

Open the vehicle with the Mobility Card (hold at the checkpoint). The charge flap is located on the driver's side at the front under the left headlight. Behind the flap is a button with a plug symbol: this must be pressed to unlock the cable.

The cable remains at the charging point (and must be hung back in the holder). Close the charge flap with a light pressure.





### 2. Setting off

A. If you haven't done so already, log in at the checkpoint with the Mobility Card. To start the vehicle, put your foot on the brake and turn the key in the ignition lock all the way to the right until the "Ready" indicator appears (Figure B).

Please note: if too much time elapses between your first log-in with the card and setting off, hold the Mobility card up to the checkpoint again.

- B. When the "READY" indicator light comes on, the vehicle is ready to drive (noiseless). Otherwise, repeat the process. The handbrake may have to be released. (Lever left of steering wheel.)
- C. Engage driving position "D" (normal forward gear) or "R" (reverse) as required, keeping your foot on the brake.

### 3. Whilst driving

The motor of an electric car is virtually silent. Up to 30 km/h, however, the vehicle generates a synthetic sound to alert pedestrians.

#### Range according to the WLTP test cycle Under normal driving conditions

340 km

Please note: if the range is less than 20 km, the vehicle must be driven to a charging point immediately.

### 4. After completing your journey

Park the vehicle forwards in the Mobility bay – the charging socket is located under the left headlight. Engage driving position P (park) and pull the handbrake on.

Open the charge flap using light pressure. The inner flap (which acts as a dust cap) must be opened by hand. Take the cable from the charging point and insert it into the vehicle. The cable is automatically locked. You'll see a yellow LED by the socket, which means the vehicle is establishing a connection to the charging point. After approx. 30 seconds, the LED turns green, which means the vehicle is charging.



Have you removed all personal belongings from the vehicle? Lock the car using the Mobility Card (hold it at the checkpoint).





Thanks for using Mobility and see you soon.

# mobility

## CHARGING INSTRUCTIONS - eVito

### 1. On-the-go charging at a GOFAST rapid-charging station

See here for details of the locations:








Engage driving position P (park) and pull the handbrake on. Open the charge flap. Proceed in the same way as in the section "After completing your journey".

The inner flap (which acts as a dust cap) must be opened by hand

Take the DC cable from the charging point and plug it into the vehicle. Start the charging process using the GOFAST charging card in the vehicle's glove compartment. Follow the instructions on the charging point display. In the event of problems, call the number on the charging point.





- 1. Lock status indicator light
- 2. Status display
- 3. Charge indicator light

~ 100 km ~ 65 mins

mobility

### 2. On-the-go charging at a Type 2 AC fast-charging station

Proceed as for charging at a rapid-charging station. In some cases, the charge cables are permanently connected to the charging point; otherwise use the charge cable in the vehicle's luggage compartment. Don't forget to take this with you when you've finished charging.



Depending on the provider, the charging process is started automatically via an app or payment by credit card (the customer can bill Mobility if payment by credit card is required). The GOFAST charging card in the vehicle's glove compartment can also be used. If necessary, contact the charging point's provider.

If the charging process has been started correctly, charge indicator "2" at the charging socket flashes green. Check this to make sure.

Range after 20 minutes of Type 2 AC charging at maximum charging r Time required for 80% charge

~ 13 km 6 hrs 32 mins

### 3. Additional charge cable

If there are no charge cables at a charging point, you'll find one in the vehicle's luggage compartment. This is compatible with charging points which have a Type 2 plug. Don't forget to put it back in the luggage compartment after charging.



If the charging process has been started correctly, charge indicator "2" at the charging socket flashes green.

